



Home Termite Infestations

Termites are small, white, tan, or black insects that can cause severe destruction to wooden buildings. Termite pests in California include drywood, dampwood and subterranean species. These pests cause serious damage to wooden structures and posts and may also attack stored food, books and household furniture.

If you see these signs in your house, you may have termites:

- Sawdust-like piles near wood surfaces or elongated, pellet-shaped droppings.
- Dirt or mud-like tubes or trails on outside walls, wooden beams or in crawl spaces. The mud tubes are typically about the diameter of a pencil, but sometimes can be thicker.
- Darkening or blistering of wooden structural members (like windowsills); wood in damaged areas is typically thin, may sound hollow, and easily punctured with a knife or screwdriver.
- Swarming winged insects inside the structure, especially in the spring or fall. Termite swarmers emerging from tree stumps, woodpiles, and other locations in the yard do not necessarily mean the house is infested. On the other hand, if winged termites are seen emerging from the base of a foundation wall or adjoining porches and patios, there's a good chance the house is also infested. (People often confuse winged termites with ants which may swarm at the same time of year. Termites have straight antennae, uniform waists and wings of equal size. Ants have elbowed antennae, constricted waists and forewings that are longer than the hind wings.)

Sometimes there will be no sign the home is infested. Termite infestations can go undetected for years, hidden behind walls, floor coverings or insulation. Termite feeding and damage can even progress undetected in wood that is exposed because the outer surface is usually left intact.

If you think you have termites, usually it is advisable to hire a professional pest control company to carry out the inspection and control program. Before making an appointment, make sure the company is registered and in good standing by calling the Structural Pest Control Board (SPCB) at **(916) 561-8708**, or toll-free **(800) 737-8188**, or go to the SPCB Web site, www.pestboard.ca.gov.

Take your time when selecting a company. Termites damage wood slowly; the amount of damage caused by taking an extra day, week or month to make an informed decision is usually insignificant. Avoid firms that try to pressure you into signing a contract immediately with "specials" or scare tactics. The overall quality of the job depends less on the salesperson than on the individual who does the work. A safe and effective treatment requires an experienced technician.

If the inspection finds evidence of drywood termites, you have several options, depending on the degree of infestation. **Fumigation** and **heating** of the entire house are the only choices that ensure eradication in the entire structure. If the infestation is contained in a small area, local or spot control may be effective; however, hidden infestations in other parts of the structure will not be eradicated.

For a summary of commercially available termite management options, and tips on how to prevent termites, go to <http://www.ipm.ucdavis.edu/>, the University of California Integrated Pest Management Web site, click on "Homes, gardens," then type "termites" in the search box. Or go directly to <http://www.ipm.ucdavis.edu/PMG/PESTNOTES/pn7440.html>.

Enforcement/Complaints

916-561-8708

1-800-737-8188

Fax

916-263-2469

E-mail

pestboard@dca.ca.gov

Web Site

www.pestboard.ca.gov

Mission Statement



The Structural Pest

*Control Board protects
consumers by
regulating the structural
pest control industry
to promote the health,
safety, and general
welfare of the public.*



Total (Whole-House) Eradication

There are two methods for total or whole-house eradication of drywood termites—fumigation and heat. For **fumigation**, you must remove all pets and plants and remove or seal medications and food. You must stay out of the house from six hours to one week, depending on the type of infestation, the size of the house and other factors. The house is then enclosed in a “tent” of vinyl-coated nylon tarps or sealed with plastic, tape, or other materials. The fumigator will post a sign on the property when it is safe to return. (NOTE: Subterranean termites require separate treatments to create a barrier between the building and their nest in the ground.) For the **heat** method, pets, plants and other items that might be damaged by high temperatures must be removed. The house is then covered with tarps. Hot air is blown in until the inside temperature reaches 140° to 150°F and the temperature of the structural timbers reaches 120°F. The time to complete this procedure varies from one structure to another, depending on factors such as the building’s construction and the weather. The procedure may not be practical for structures that cannot be heated evenly.

Local or Spot Control

Local or spot control methods include the use of pesticides, electric current, extreme cold, localized heat, microwave energy or any combination of these methods. Local or spot control also includes the removal and replacement of infested structural timber. These methods are intended to remove or kill termites only within the specific targeted area, leaving open the possibility of other undetected infestations within the structure. **These treatments are NOT designed for whole-house eradication.** Any pest control company that claims whole-house results with local or spot control methods is guilty of false advertising and should be reported. Local or spot treatment with **pesticides** involves drilling and injecting pesticides into infested timbers as well as the topical application of toxic chemicals. The **electric-current** method involves delivering electric energy to targeted infestations. For the **extreme-cold** method, liquid nitrogen is pumped into wall voids next to suspected infestation sites, reducing the area to -20°F. The **localized heat** method involves heating infested structural timbers to 120°F. The **microwave** method kills termites by directing microwaves into termite-infested wood.

Complaints

If you have a complaint about a pest control company or want more information, call the Structural Pest Control Board:

916-561 8708 — in Sacramento

1-800-737-8188 — outside Sacramento

You can e-mail the SPCB at pestboard@dca.ca.gov, or write to:

Structural Pest Control Board

2005 Evergreen Street, Suite 1500

Sacramento, CA 95815

You can also download a complaint form from the SPCB Web site, www.pestboard.ca.gov

The Structural Pest Control Board licenses and regulates pest management professionals engaged in the business of structural pest control to ensure that licensees meet minimum qualifications and levels of competency to provide safe and effective services to the public. SPCB staff addresses complaints filed by consumers through mediation and enforcement of the Structural Pest Control Act.